

B&D Tri Tran - TB5/6/7

PROGRAMMING INSTRUCTIONS




PowerDrive & Roll A Pro and Motors prior to 2021

OPENER: Press the CODE SET button and release, LED will illuminate to indicate Learn Mode.

NEW REMOTE: Press the button you wish to activate your opener, LED will begin to flash

NEW REMOTE: Press the button again, LED will illuminate then turn off



Deleting ALL remotes from Opener

Hold the CODE SET button on Opener for approx. 6 seconds, LED will blink rapidly to confirm all remotes erased.

Smart Pro, Smart and Secure

OPENER: Remove the controls cover to access the buttons

OPENER: Press MODE until the remote indicator LED is lit


OPENER: Press and Hold the DOWN Arrow, remote indicator light will flash rapidly

REMOTE: Press the button you wish to activate you opener

REMOTE: Press the button again

OPENER: Release the DOWN arrow

OPENER: Press MODE button to exit Learn Mode, Replace the Control covers



Remote Indicator LED

Deleting ALL remotes from Opener

Press the MODE button until the Remote Indicator is lit

Press and hold the MODE button for 10 seconds

Press Mode button to leave learn mode.



Warning: This product may contain a pre-installed Lithium Coin Battery. Please keep product and batteries out of reach of children. Please see [button battery safety information](#) from the Australian Competition & Consumer Commission (ACCC) for more information.