


# SteelLine/ BOSS HT3 Remote

## PROGRAMMING INSTRUCTIONS




### Programming the Remote (OL4)

- **OPENER:** Remove the face plate on the motor to locate the radio set button.
- **OPENER:** Press the Radio Set Button for 1-2 seconds, courtesy light will flash once then stay on for 30 seconds)
- **NEW REMOTE:** Press the button on your NEW remote, courtesy light flashes twice.



### Programming the Remote (OL6 & RD11)

- **OPENER:** Press Radio Set button for 1-2 seconds, OK led will stay on.
- **NEW REMOTE:** Press the button on your NEW remote, OK led will switch off.



### Clearing the Openers Memory

- **OPENER:** Press and hold the Radio Set button for 5-8 seconds, OL4 - courtesy light will flash 7 times.
- **OL6 and RD11 - OK light will flash 3 times**



Warning: This product may contain a pre-installed Lithium Coin Battery. Please keep product and batteries out of reach of children. Please see [button battery safety information](#) from the Australian Competition & Consumer Commission (ACCC) for more information .