

CODE EZY Sonic

Herculift Garage Doors

PROGRAMMING INSTRUCTIONS




Programming a New Remote

Locate the Learn button. Most of the Sectional/Tilt Doors there is a control panel on the back of the motor. Roller Doors have a light cover covering the control panel. Remove the light cover to reveal the control panel.



Motor: Press the "Learn" button once, LED will glow Red

New Remote: Press the button on remote twice
First press will turn off the Red LED, and the second will make the LED flash.



Clearing the Memory

Motor: Press and HOLD the "Learn" button for around 8 seconds, LED will switch to red then turn off once memory cleared.



Warning: This product may contain a pre-installed Lithium Coin Battery. Please keep product and batteries out of reach of children. Please see [button battery safety information](#) from the Australian Competition & Consumer Commission (ACCC) for more information.