

# GLIDEROL TM390 GEN2

## Blue Button

### PROGRAMMING INSTRUCTIONS



#### Programming to Genesis and Genesis Optima

**Motor:** Press the "CODE" button, "-.-." will show on display

**New Remote:** Press and Hold the Desired button on your remote until the dots flash on display.

#### Clearing the Memory

**Motor:** Press and HOLD the "CODE" button for 8 seconds, Dots on display will disappear once memory cleared.




#### Programming to Rollamatic Opener

**Motor:** Press and HOLD the "ENTER" button for 2 seconds, unit will beep twice

**Motor:** Use the arrow button (up or down) to select the "Learn" option, then press "ENTER", unit will beep three times

**New Remote:** Press and HOLD the desired button on your remote until all LED's on status bar are lit up.



#### Clearing the Memory

**Motor:** Press and HOLD the "ENTER" button for 5 seconds



Warning: This product may contain a pre-installed Lithium Coin Battery. Please keep product and batteries out of reach of children. Please see [button battery safety information](#) from the Australian Competition & Consumer Commission (ACCC) for more information .