

BENINCA

PROGRAMMING INSTRUCTIONS



Pairing a New Remote via a Genuine Beninca Remote


You will need to be within close proximity to opener..

- With a needle or safety pin, press the hidden button found on the back of your Genuine Working Remote
- LED light on the WORKING remote will illuminate.
- Within 10 seconds of the LED light going off on WORKING remote press a button on your NEW Remote.



Pairing a New Remote via Control Panel/Receiver

- OPENER: Open the case of the motor to reveal the receiver located next to your control board.
- RECEIVER: Press and Hold the Programming button (PGM) until LED light illuminates on receiver
- NEW REMOTE: Press the button on NEW remote
- Wait 10 seconds for receiver to exit programming mode.



Deleting all Remotes from Opener

OPENER: HOLD DOWN the Program button for approx 10 seconds.

Pairing via a Built in Receiver with LCD Screen

Follow the below actions on the control panel to program a NEW remote.



Warning: This product may contain a pre-installed Lithium Coin Battery. Please keep product and batteries out of reach of children. Please see [button battery safety information](#) from the Australian Competition & Consumer Commission (ACCC) for more information .